

Machine Learning Echo Localization

Principle

The aim is to be able to localize in a room a robot using echo. The localization is done in 2D. The room environment has to be previously learnt. Space is divided by zones. For each zone the robot makes echo scanner all around itself. This operation is repeated in order to get measurement diversity. These measurements are used by a logistic regression system to learn the environment. By doing so the robot is learning the environment.

Then it is possible to localize the robot in the room. The robot has to do a 360° scan. The measurement is used by the previously defined algorithm to localize the robot in a zone and find the orientation of the robot.

The robot is moving in 2D. The space to cover is divided in rectangular zones of the same shape. The space is oriented following 2 orthogonal axes X and Y. Each zone is identified by a number that increase following X and then Y.

The 360° scan is done by rotating the echo sonar of a defined number of steps. The number of steps is the same for the learning and localization phase.

For instance a space of 90cm x 180 cm divided in 28 squares (30cm x 30xcm) form zones.

	0	30	60	90	X
0	1	2	3	4	
30	5	6	7	8	
60	9	10	9	9	
90	13	14	15	16	
120	17	18	19	20	
150	21	22	23	24	
180	25	26	27	28	
Y					

Details of implementation

Learning phase

Getting data

The robot has a servo-motor that can rotate of 180° and to echo sensors that are 180° oriented. One is oriented at the rest to the front and the other to the back of the robot.

For each scan the robot provides (angle, front echo distance, back echo distance) to the localization algorithm.

During the learning phase each scan is identified by a unique number.

The scan is done with 15 (nbStepsRotation) rotations of 12.857° that lead to a complete 360° rotation. That gives 2x15 distances for a specific localization. The first and the last measurement of a scan are quite the same (measuring the same position with the opposite echo sensor).

During the learning phase the robot keep the same orientation.

Around 15 scans have been done for each zone during the learning phase in order to provide enough diversity to the learning system.

nbZones is the number of different zones.

At the end of the learning scans $15 \times \text{nbStepsRotation} \times \text{nbZones}$ records; each records contains a scan identifier (idscan), the servo motor orientation, the front distance and back distance the X and Y position if the robot.

For the same idsan we have nbStepsRotation records.

Learning system

The collected data (scanResult.txt) are used as input for the learning system.

The pre-processing step is manually done with an excel tool. The aim is to allocate a unique number to identify zone depending on X and Y position.

During the first step (extendScanResult) of the learning system the data are extended by a virtual rotation of nbStepsRotation steps. By doing so we can simulate what would be the scan result if the robot has been differently oriented. The zone identifier is modified to introduce the angle point of view. These new identifier will become the feature values of the logistic regression calculation. The output is a matrix extScanResult.

During the second step (createMatrixTraining) of the learning system data are extrapolated in order to provide a 360° scan with one degree step. The outputs are 2 matrix trainMat(containing the measurements) and trainResult (containing the target values).

The third step (learnScanRobot) does the logistic regression calculation. learnScanRobot needs to input values (lambda, maxIter) lambda to tune over/under fitting and maxIter to limit the number of iteration.

During the first experience we got that (100000,5000) are the best values.

The output is a matrix all_theta.

Localization

Getting data

The robot makes a single 360° scan and sends data to the calculation system. The target is to do the same "nbStepsRotation" rotations than during the learning phase but the experience show that it could even work with a little less. The data are stored in scanToAnalyse.txt.

Calculation

The data are extrapolated in order to provide a 360° scan with one degree step, stored in a matrix analyseMat and then proceeded by predictOneVsAll (all_theta,analyseMat) in order to bet the predicted localization value. At the end this value is analyse to provide zone number and angle.

On top of that 2 graphs are provided. The first one shows the echograph to be determined and the second one the echographs of selected training set (containing all the measurement made at the same zone during the learning phase).

